



Mezzalad

Assembly Instructions

* Pro Version shown

Mezzalad Assembly

IMPORTANT: To avoid assembly problems follow these instructions exactly.

Step 1 - At the top of the ladder, Fix the Upper Handrail to the Ladder Stile at A & B using the 6 x 40mm bolts nuts and washers - *Finger tight only*. (See illustration No. 1)

Note: Bolt Heads should be seen from this face

Step 2 - At the centre of the ladder, fix the lower end of the Upper Handrail to the Ladder Stile at C & the upper end of the Lower Handrail to the Ladder Stile at D. Use the 6 x 40mm bolts nuts and washers - *Finger tight only*. (See illustration No. 2)

Step 3 - At the base of the ladder, fix the lower end of the Lower Handrail to the Ladder Stile at E & F using the 6 x 40mm bolts nuts and washers. **NOW** tighten all bolts. (See illustration No. 3)

Step 4 - Assemble the Tube of the Safety Gate to the Gate Hinge/Latch. Locate the end of the Tube with the hole in it. Seat this end into the Gate Hinge/Latch and Insert a Clevis Pin into the hole. (See illustration No. 4)

Step 5 - Push the Clevis Pin thru the Tube and Gate/Latch, fit the Washer and secure with the R Clip. (See illustration No. 5)

Step 6 - Fit the Safety Gate to the top of the Handrail. It may be mounted to either the left or right side. Use a Clevis Pin, R Clip and Washer to secure. (See illustration No. 6)

Step 7 - Fit the remaining Gate Hinge/Latch to the top of the opposite Handrail. Place the Nylon Washer between the Handrail and Gate Hinge/Latch and pass the bolt thru the assembly. Fit the Washer and Nut - *Finger tight only*. (See illustration No. 7)

Step 8 - Lower the Safety Gate into the Latch (See illustration No. 8)

Step 9 - Tighten the Gate Latch bolt. (See illustration No. 9)

Mezzalad Assembly

Step 10 - Ensure that a clear space of 770mm is available at the Mezzalad mounting position. Lay the Mezzalad against the Upper floor and adjust the position so that the top step is flush with the Upper floor. Position the Mezzalad in the centre of the opening. (See illustration No. 10)

Step 11 - Carefully ascend the ladder and engage mounting bracket into the slot at the left hand side of the Mezzalad. (See illustration No. 11)

Note: Illustration No. 11 shows a floor mounting application. For a wall mounting application place this bracket on the right hand side.

Step 12 - Position the Bracket Tab against the wall for a floor mounting, or floor for a wall mounting application. Fasten the bracket to the floor or wall using appropriate fasteners (not supplied). One 10mm diameter hole and 2 x 5mm diameter holes are provided in each bracket. (See illustration No. 12)

Step 13 - Engage the remaining bracket into the slot on the opposite side of the Mezzalad. Repeat the instructions above in step 12 and fasten the bracket. Pull the ladder out fully to the using (open) position and check that the upper surface of the top step is flush with the upper floor. Also check that the Bracket Tabs are flush with the floor or wall (dependant on chosen mounting position).

USER INSTRUCTIONS

Before use see the

User Instructions

Use this manual to form part of your Risk Assessment

WARRANTY

Thank you for choosing StockMaster. Your safety is in good hands. Register your 2 year warranty online at

www.stockmaster.co

Mezzalad Assembly

Mezzalad Assembly




Illustration 1




Illustration 2




Illustration 5



Illustration 6




Illustration 3




Illustration 4



Illustration 7



Illustration 8

Mezzalad Assembly



Illustration 9



Illustration 10



Illustration 11




Illustration 12